

PVS Screen Stuck In Component Mode

S-TRc, S-TRx, S-UBx, S-RBx

The Personal Viewing Screens (PVS) on the S Series products do not have an "INPUT" button to change from component to video (TV) mode.



Treadmills



Bikes

If a PVS happens to turn to the component mode, press **7 8 9** to change modes. Do not press and hold.

Note: Some of the earlier versions of PVS CCB software do not have this feature. The software will need to be updated or a the CCB will need to be replaced with one that has the latest software.